

TRUX Stainless Steel  
Accessories for WESTERN STAR

Heritage Sunvisor **TSUN-W2 Fit:1987-2008**

INSTALLATION INSTRUCTIONS

1. Remove existing sunvisor and brackets.
2. Install the new brackets in the same place as the ones you've just removed.
3. Holding the center bracket in the center of the cab (~19" from bottom of windshield), transfer the 6 mounting hole locations to the cab.
4. Drill six 1/8" holes into the marked locations. Apply silicone caulking over the hole area, then install bracket using the supplied #8 self tapping screws.
5. Place both visor halves over installed brackets. Install the 2 end bolts through both visor ends into cab. Secure visor to the center bracket using the supplied #10-32 hardware.
6. Install the remaining 1/4" and 1/2" bolts and tighten all fasteners.
7. Remove the protective plastic and clean with glass cleaner, if necessary.